
CHAPTER 1

ENVIRONMENTAL

MONITORING PROGRAM

INFORMATION

Introduction

The high-level radioactive waste (HLW) presently stored at the West Valley Demonstration Project (WVDP) is the byproduct of the reprocessing of spent nuclear fuel conducted during the late 1960s and early 1970s by Nuclear Fuel Services, Inc.(NFS).

Since the Western New York Nuclear Service Center (WNYNSC) is no longer an active nuclear fuel reprocessing facility, the environmental monitoring program focuses on measuring radioactivity and chemicals associated with the residual effects of NFS operations and the Project's high-level waste treatment and low-level waste management operations. The following information about the operations at the WVDP and about radiation and radioactivity will be useful in understanding the activities of the Project and the terms used in reporting the results of environmental testing measurements.

Radiation and Radioactivity. Radioactivity is a process in which unstable atomic nuclei spontaneously disintegrate or "decay" into atomic nuclei of another isotope or element. (See *isotope*, p.5, in the Glossary.) The nuclei decay until only a stable, nonradioactive isotope remains. Depending on the isotope, this process can take anywhere from less than a second to hundreds of thousands of years.

As atomic nuclei decay, radiation is released in three main forms: alpha particles, beta particles, and gamma rays. By emitting energy or particles, the nucleus moves toward a less energetic, more stable state.

Alpha Particles. An alpha particle, released by decay, is a fragment of a much larger nucleus. It consists of two protons and two neutrons (similar to a helium atom nucleus) and is positively charged. Compared to beta particles, alpha particles are relatively large and heavy and do not travel very far when ejected by a decaying nucleus. Alpha radiation, therefore, is easily stopped by a thin layer of material such as paper or skin. However, if radioactive material is ingested or inhaled, the alpha particles released inside the body can damage soft internal tissues because all of their energy is absorbed by tissue cells in the immediate vicinity of the decay. An example of an alpha-emitting radionuclide is the uranium isotope with an atomic weight of 232 (uranium-232). Uranium-232 is in the high-level waste mixture at the WVDP as a result of a thorium-based nuclear fuel reprocessing campaign conducted by NFS and has been previously detected on occasion in liquid waste streams.

Beta Particles. A beta particle is an electron that results from the breakdown of a neutron in a radioactive nucleus. Beta particles are small compared to alpha particles, travel at a higher speed

(close to the speed of light), and can be stopped by a material such as wood or aluminum less than an inch thick. If beta particles are released inside the body they do much less damage than an equal number of alpha particles. Because they are smaller and faster and have less of a charge, beta particles deposit energy in fewer tissue cells and over a larger volume than alpha particles. Strontium-90, a fission product (see Glossary, p.4), is an example of a beta-emitting radionuclide. Strontium-90 is found in the stabilized supernatant.

Gamma Rays. Gamma rays are high-energy “packets” of electromagnetic radiation, called photons, that are emitted from the nucleus. They are similar to x-rays but generally have a shorter wavelength and therefore are more energetic than x-rays. If the alpha or beta particle released by the decaying nucleus does not carry off all the energy generated by the nuclear disintegration, the excess energy may be emitted as gamma rays. If the released energy is high, a very penetrating gamma ray is produced that can be effectively reduced only by shielding consisting of several inches of a heavy element, such as lead, or of water or concrete several feet thick. Although large amounts of gamma radiation are dangerous, gamma rays are also used in many lifesaving medical procedures. An example of a gamma-emitting radionuclide is barium-137m, a short-lived daughter product of cesium-137. Both barium-137m and cesium-137 are major constituents of the WVDP high-level radioactive waste.

Measurement of Radioactivity. The rate at which radiation is emitted from a disintegrating nucleus can be described by the number of decay events or nuclear transformations that occur in a radioactive material over a fixed period of time. This process of emitting energy, or radioactivity, is measured in curies (Ci) or becquerels (Bq).

The curie is based on the decay rate of the radionuclide radium-226 (Ra-226). One gram of radium-226 decays at the rate of 37 billion nuclear

disintegrations per second (3.7×10^{10} d/s), so one curie equals 37 billion nuclear disintegrations per second. One becquerel equals one decay, or disintegration, per second.

Very small amounts of radioactivity are sometimes measured in picocuries. A picocurie is one-trillionth (10^{-12}) of a curie, equal to 3.7×10^{-2} disintegrations per second, or 2.22 disintegrations per minute.

Measurement of Dose. The amount of energy absorbed by the receiving material is measured in rads (radiation absorbed dose). A rad is 100 ergs of radiation energy absorbed per gram of material. (An erg is the approximate amount of energy necessary to lift a mosquito one-sixteenth of an inch.) “Dose” is a means of expressing the amount of energy absorbed, taking into account the effects of different kinds of radiation.

Alpha, beta, and gamma radiation affect the body to different degrees. Each type of radiation is given a quality factor that indicates the extent of human cell damage it can cause compared with equal amounts of other ionizing radiation energy. Alpha particles cause twenty times as much damage to internal tissues as x-rays, so alpha radiation has a quality factor of 20 compared to gamma rays, x-rays, or beta particles, which have a quality factor of 1.

The unit of dose measurement to humans is the rem (roentgen-equivalent-man). Rems are equal to the number of rads multiplied by the quality factor for each type of radiation. Dose can also be expressed in sieverts. One sievert equals 100 rem.

Environmental Monitoring Program Overview

Human beings may be exposed to radioactivity primarily through air, water, and food. At the WVDP all three pathways are monitored, but air and surface water path-

Ionizing Radiation

Radiation can be damaging if, in colliding with other matter, the alpha or beta particles or gamma rays knock electrons loose from the absorber atoms. This process is called ionization, and the radiation that produces it is referred to as ionizing radiation because it changes an electrically neutral atom, in which the positively charged protons and the negatively charged electrons balance each other, into a charged atom called an ion. An ion can be either positively or negatively charged. Various kinds of ionizing radiation produce different degrees of damage.

Potential Effects of Radiation

The biological effects of radiation can be either somatic or genetic. Somatic effects are restricted to the person who has been exposed to radiation. For example, sufficiently high exposure to radiation can cause clouding of the lens of the eye or loss of white blood cells.

Radiation also can cause chromosomes to break or rearrange themselves or to join incorrectly with other chromosomes. These changes may produce genetic effects and may show up in future generations. Radiation-produced genetic defects and mutations in the offspring of an exposed parent, while not positively identified in humans, have been observed in some animal studies.

The effect of radiation depends on the amount absorbed within a given exposure time. The only observable effect of an instantaneous whole-body dose of 50 rem (0.5 Sv) might be a temporary reduction in white blood cell count. An instantaneous dose of 100-200 rem (1-2 Sv) might cause additional temporary effects such as vomiting but usually would have no long-lasting side effects.

Assessing biological damage from low-level radiation is difficult because other factors can cause the same symptoms as radiation exposure. Moreover, the body apparently is able to repair damage caused by low-level radiation.

The effect most often associated with exposure to relatively high levels of radiation appears to be an increased risk of cancer. However, scientists have not been able to demonstrate with certainty that exposure to low-level radiation causes an increase in injurious biological effects, nor have they been able to determine if there is a level of radiation exposure below which there are no biological effects.

Background Radiation

Background radiation is always present, and everyone is constantly exposed to low levels of such radiation from both naturally occurring and manmade sources. In the United States the average total annual exposure to this low-level background radiation is estimated to be about 360 millirem (mrem) or 3.6 millisieverts (mSv). Most of this radiation, approximately 295 mrem (2.95 mSv), comes from natural sources. The rest comes from medical procedures, consumer products, and other manmade sources. (See p. 4-3 in Chapter 4, Radiological Dose Assessment.)

Background radiation includes cosmic rays, the decay of natural elements such as potassium, uranium, thorium, and radon, and radiation from sources such as chemical fertilizers, smoke detectors, and televisions. Actual doses vary depending on such factors as geographic location, building ventilation, and personal health and habits.

ways are the two primary means by which radioactive material can move off-site.

The geology of the site (types of soil and bed-rock), the hydrology (location and flow of surface water and groundwater), and meteorological characteristics of the site (wind speed, patterns, and direction) are all considered in evaluating potential exposure through the major pathways.

The on-site and off-site monitoring program at the WVDP includes measuring the concentration of alpha and beta radioactivity, conventionally referred to as “gross alpha” and “gross beta,” in air and water effluents. Measuring the total alpha and beta radioactivity from key locations, which can be done within a matter of hours, produces a comprehensive picture of on-site and off-site levels of radioactivity from all sources. In a facility such as the WVDP, frequent updating and tracking of the overall levels of radioactivity in effluents is an important tool in maintaining acceptable operations.

More detailed measurements are also made for specific radionuclides. Strontium-90 and cesium-137 are measured because they have been previously detected in WVDP waste materials. Radiation from other important radionuclides such as tritium or iodine-129 are not sufficiently energetic to be detected by gross measurement techniques, so these must be analyzed separately using methods with greater sensitivity. Heavy elements such as uranium, plutonium, and americium require special analysis to be measured because they exist in such small concentrations in the WVDP environs.

The radionuclides monitored at the Project are those that might produce relatively higher doses or that are most abundant in air and water effluents. Because manmade sources of radiation at the Project have been decaying for more than twenty years, the monitoring program does not routinely include short-lived radionuclides, i.e., isotopes with a half-life of less than two years,

which would have only 1/1,000 of the original radioactivity remaining. (See Appendix B [pp. B-1 through B-44] for the schedule of samples and radionuclides measured and Appendix K, Table K-1 [p.K-3] for related Department of Energy [DOE] protection standards, i.e., derived concentration guides [DCGs] and half-lives of radionuclides measured in WVDP samples.)

Data Reporting. Because the decay of radioactive atoms is a random process, there is an inherent uncertainty associated with all environmental radioactivity measurements. This can be demonstrated by repeatedly measuring the number of atoms that decay in a radioactive sample over some fixed period of time. The result of such an experiment would be a range of values for which the average value would provide the best indication of how many radioactive atoms were present in the sample.

However, in actual practice a sample of the environment usually is measured for radioactivity just once, not many times. The inherent uncertainty of the measurement, then, stems from the fact that it cannot be known whether the result that was obtained from one measurement is higher or lower than the “true” value, i.e., the average value that would be obtained if many measurements had been taken.

The term confidence interval is used to describe the range of measurement values above and below the test result within which the “true” value is expected to lie. This interval is derived mathematically. The width of the interval is based primarily on a predetermined confidence level, i.e., the probability that the confidence interval actually encompasses the “true” value. The WVDP environmental monitoring program uses a 95% confidence level for all radioactivity measurements and calculates confidence intervals accordingly.

The confidence interval around a measured value is indicated by the plus-or-minus (\pm) value following the result, e.g., $5.30 \pm 3.6\text{E-}09 \mu\text{Ci/mL}$, with

the exponent of 10^{-9} expressed as “E-09.” Expressed in decimal form, the number would be $0.0000000053 \pm 0.0000000036 \mu\text{Ci/mL}$. A sample measurement expressed this way is correctly interpreted to mean “there is a 95% probability that the concentration of radioactivity in this sample is between $1.7\text{E-}09 \mu\text{Ci/mL}$ and $8.9\text{E-}09 \mu\text{Ci/mL}$.”

If the confidence interval for the measured value includes zero (e.g., $5.30 \pm 6.5\text{E-}09 \mu\text{Ci/mL}$), the value is considered to be below the detection limit. The values listed in tables of radioactivity measurements in the appendices include the confidence interval regardless of the detection limit value.

In general, the detection limit is the minimum amount of constituent or material of interest detected by an instrument or method that can be distinguished from background and instrument noise. Thus, the detection limit is the lowest value at which a sample result shows a statistically positive difference from a sample in which no constituent is present.

Nonradiological data conventionally are presented without an associated uncertainty and are expressed by the detection limit prefaced by a “less-than” symbol ($<$) if that analyte was not measurable. (See also Data Assessment and Reporting [p.5-7] in Chapter 5, Quality Assurance.)

Changes in the 1998 Environmental Monitoring Program. Changes in the 1998 environmental monitoring program enhanced the environmental sampling and surveillance network in order to support current activities and to prepare for future activities.

- The quarterly environmental monitoring data report (QEMDR) was discontinued in mid-1998. The annual (radioactive) effluent information system/on-site discharge information system (EIS/ODIS) also was discontinued. Data formerly contained in these two reports are now evaluated monthly in the monthly trend analysis report

Derived Concentration Guides

A derived concentration guide (DCG) is defined by the DOE as the concentration of a radionuclide in air or water that, under conditions of continuous exposure by one exposure mode (i.e., ingestion of water, submersion in air, or inhalation) for one year, would result in an effective dose equivalent of 100 mrem (1 mSv) to a “reference man.” These concentrations — DCGs — are considered screening levels that enable site personnel to review effluent and environmental data and to decide if further investigation is needed. (See Table K-1, Appendix K, p.K-3 for a list of DCGs.)

DOE Orders require that the hypothetical dose to the public from facility effluents be estimated using specific computer codes. (See Dose Assessment Methodology [p.4-6] in Chapter 4, Radiological Dose Assessment.) Doses estimated for WVDP activities are calculated using actual site data and are not related directly to DCG values.

Dose estimates are based on a sum of isotope quantities released and the dose equivalent effects for that isotope. For liquid effluent screening purposes, percentages of the DCGs for all radionuclides present are added: if the total percentage of the DCGs is less than 100, then the effluent released complies with the DOE guideline.

Although the DOE provides DCGs for airborne radionuclides, the more stringent U.S. Environmental Protection Agency (EPA) National Emissions Standards for Hazardous Air Pollutants (NESHAP) apply to Project airborne effluents. As a convenient reference point, comparisons with DCGs are made throughout this report for both air and water samples.

(MTAR) and are summarized in full in the annual site environmental report (SER).

- Air monitoring point ANSUPCV was discontinued in 1998 because the supercompactor was decommissioned and shipped off-site in May 1998.
- Effluent point ANLLWTVC was discontinued in 1998 because the processes housed in the O2 building were transferred to the new low-level waste treatment (LLW2) facility.
- Monitoring point ANLLW2V, associated with the new LLW2 facility, was added to the program in 1998.
- Co-located NRC monitoring points used to independently verify environmental radiation levels were discontinued in 1998.

Appendix B summarizes the program changes (p.B-iv) and lists the sample points and parameters measured in 1998 (pp.B-1 through B-44).

Vitrification Overview. High-level radioactive waste from NFS operations was originally stored in two of four underground tanks (tanks 8D-2 and 8D-4). The waste in 8D-2, the larger of the active tanks, had settled into two layers: a liquid — the supernatant — and a precipitate layer on the tank bottom — the sludge. To solidify the high-level waste, WVDP engineers designed and developed a process of pretreatment and vitrification.

Pretreatment Accomplishments. The supernatant (in tank 8D-2) was composed mostly of sodium and potassium salts dissolved in water. Radioactive cesium in solution accounted for more than 99% of the total radioactivity in the supernatant. During pretreatment, sodium salts and sulfates were separated from the radioactive constituents in both the liquid portion of the high-level waste and the sludge layer in the bottom of the tank.

Pretreatment of the supernatant began in 1988. The integrated radwaste treatment system (IRTS) reduced the volume of the high-level waste needing vitrification by producing low-level waste stabilized in cement: The supernatant was passed through zeolite-filled ion exchange columns in the supernatant treatment system (STS) to remove more than 99.9% of the radioactive cesium. The resulting liquid was then concentrated by evaporation in the liquid waste treatment system (LWTS). This low-level radioactive concentrate was blended with cement in the cement solidification system (CSS) and placed in 269-liter (71-gal) steel drums. The cement-stabilized waste form has been accepted by the U.S. Nuclear Regulatory Commission (NRC). Finally, the steel drums were stored in an on-site aboveground vault, the drum cell. Processing of the supernatant was completed in 1990, with more than 10,000 drums of cemented waste produced.

The sludge that remained was composed mostly of iron hydroxide. Strontium-90 accounted for most of the radioactivity in the sludge. Pretreatment of the sludge layer in high-level waste tank 8D-2 began in 1991. Five specially designed 50-foot-long pumps were installed in the tank to mix the sludge layer with water in order to produce a uniform sludge blend and to dissolve the sodium salts and sulfates that would interfere with vitrification. After mixing and allowing the sludge to settle, processing of the wash water through the integrated radwaste treatment system began. Processing removed radioactive constituents for later solidification into glass, and the wash water containing salt was then stabilized in cement.

Sludge washing was completed in 1994 after approximately 765,000 gallons of wash water had been processed. About 8,000 drums of cement-stabilized wash water were produced.

In January 1995, high-level waste liquid stored in tank 8D-4 was transferred to tank 8D-2. (Tank 8D-4 contained THOREX high-level radioactive

waste, which had been produced by a single reprocessing campaign of a special fuel containing thorium that had been conducted from November 1968 to January 1969 by the previous facility operators.) The resulting mixture was washed and the wash water was processed. The IRTS processing of the combined wash waters was completed in May 1995.

In all, through the supernatant treatment process and the sludge wash process, more than 1.7 million gallons of liquid had been processed by the end of 1995, producing a total of 19,877 drums of cemented low-level waste.

As one of the final steps, the ion-exchange material (zeolite) used in the integrated radwaste treatment system to remove radioactivity was blended with the washed sludge before being transferred to the vitrification facility for blending with the glass-formers. In 1995 and early 1996 final waste transfers to high-level waste tank 8D-2 were completed in preparation for vitrification.

Preparation for Vitrification. Nonradioactive testing of a full-scale vitrification system was conducted from 1984 to 1989. In 1990 all vitrification equipment was removed to allow installation of shield walls for fully remote radioactive operations. The walls and shielded tunnel connecting the vitrification facility to the former reprocessing plant were completed in 1991.

The slurry-fed ceramic melter was fully assembled, bricked, and installed in 1993, and the cold chemical building was completed, as was the sludge mobilization system that transfers high-level waste to the melter. This system was fully tested in 1994. Several additional major systems components also were installed in 1994: the canister turntable, which positions the stainless steel canisters as they are filled with molten glass; the submerged bed scrubber, which cleans gases produced by the vitrification process; and the transfer cart, which moves filled canisters to the storage area.

Nonradiological testing ("cold" operations) of the vitrification facility began in 1995, and the first canister of nonradiological glass was produced. The WVDP declared its readiness to proceed with the necessary equipment tie-ins of the ventilation and utility systems to the vitrification facility building and tie-ins of the transfer lines to and from the high-level waste tank farm and the vitrification facility. In this closed-loop system, the transfer lines connect to multiple common lines so that material can be moved among all the points in the system. High-level waste vitrification began in 1996 and continued throughout 1998.

1998 Activities at the WVDP

The WVDP's environmental management system is an important factor in the environmental monitoring program and the accomplishment of its mission. Significant components, initiatives, and pertinent information about the work accomplished at the WVDP in 1998 are summarized below.

Vitrification. Solidification of the high-level waste in glass continued in 1998. The high-level waste mixture of washed sludge and spent zeolite from the ion-exchange process is combined in batches with glass-forming chemicals and then fed to a ceramic melter. The waste mixture is heated to approximately 2,000°F and poured into stainless steel canisters. Approximately 270 stainless steel canisters eventually will be needed to hold all of the vitrified waste. Each canister, 10 feet long by 2 feet in diameter, is filled with a uniform, high-level waste glass that will be suitable for eventual shipment to a federal repository. During Phase I (June 1996 to June 1998) 210 canisters were filled.

In 1998 more than 2.1 million curies of radioactivity were transferred to the vitrification facility and fifty-two high-level waste canisters were produced. Since the beginning of vitrification in 1996 through calendar year 1998, 230 high-level waste

canisters have been filled. Based on analysis of the first sixty-eight batches, more than 10.3 million cesium/strontium curies have been transferred to the vitrification facility and vitrified.

Environmental Management of Aqueous Radioactive Waste. Water containing radioactive material from site process operations is collected and treated in the low-level waste treatment facility (LLWTF). (Water from the sanitary system, which does not contain added radioactive material, is managed in a separate system.) The treated process water is held, sampled, and analyzed before it is released through a State Pollutant Discharge Elimination System (SPDES)-permitted outfall. In 1998, 43.5 million liters (11.5 million gal) of water were treated in the LLWTF and discharged through outfall 001, the lagoon 3 weir.

The discharge waters contained an estimated 12 millicuries of gross alpha plus gross beta radioactivity. Comparable releases during the previous thirteen years averaged about 41 millicuries per year. The 1998 release was about 29% of this average. (See Radiological Monitoring: Surface Water, Low-level Waste Treatment Facility Sampling Location [p.2-2] in Chapter 2.)

Approximately 0.20 curies of tritium were released in WVDP liquid effluents in 1998. This is 13% of the thirteen-year average of 1.57 curies.

Environmental Management of Airborne Radioactive Emissions. Ventilated air from the various points in the IRTS process (high-level waste sludge treatment, main plant and liquid waste treatment system, and the cement solidification system) and from other waste management activities is sampled continuously during operation for both particulate matter and for gaseous radioactivity. In addition to monitors that alarm if particulate matter radioactivity increases above preset levels, the sample media are analyzed in the laboratory for the specific radionuclides that are present in the radioactive materials being handled.

Air used to ventilate the facilities where radioactive material cleanup processes are operated is passed through filtration devices before being emitted to the atmosphere. These filtration devices are generally more effective for particulate matter than for gaseous radioactivity. For this reason, facility air emissions tend to contain a greater amount of gaseous radioactivity (e.g., tritium and iodine-129) than radioactivity associated with particulate matter (e.g., strontium-90 and cesium-137). However, gaseous radionuclide emissions still remain so far below the most restrictive regulatory limit for public safety that additional treatment technologies beyond that already provided by, for example, the vitrification off-gas treatment system, are not necessary.

Gaseous radioactivity emissions from the main plant in 1998 included approximately 34.5 millicuries of tritium (as hydrogen tritium oxide [HTO]) and 4.97 millicuries of iodine-129. (See Chapter 2, p.2-24, for further discussion of iodine-129 emissions from the main plant stack.) In 1997, a year in which the vitrification system was in operation for the entire year, tritium and iodine-129 emissions were 140 millicuries and 7.43 millicuries respectively.

Particulate matter radioactivity emissions from the main plant in 1998 included approximately 0.2 millicuries of beta-emitting radioactivity and 0.001 millicuries of alpha-emitting radioactivity. In 1997, beta-emitting and alpha-emitting radioactivity emissions were 0.4 millicuries and 0.001 millicuries respectively.

Unplanned Radiological Releases. There were no unplanned air or liquid radiological releases on-site or to the off-site environment from the Project in 1998.

NRC-licensed Disposal Area (NDA) Interceptor Trench and Pretreatment System. Radioactively contaminated n-dodecane in combination with tributyl phosphate (TBP) was discovered at the northern boundary of the NDA

in 1983, shortly after the DOE assumed control of the WVDP site. Extensive sampling and monitoring through 1989 revealed the possibility that the n-dodecane/TBP could migrate. To contain this subsurface organic contaminant migration, an interceptor trench and liquid pretreatment system (LPS) were built.

The trench was designed to intercept and collect subsurface water, which could be carrying n-dodecane/TBP, in order to prevent the material from entering the surface water drainage ditch leading into Erdman Brook. The LPS was installed to decant the n-dodecane/TBP from the water and to remove iodine-129 from the collected water before its transfer to the low-level waste treatment facility. The separated n-dodecane/TBP would be stored for subsequent treatment and disposal.

As in previous years, no water containing n-dodecane/TBP was encountered in the trench and no water or n-dodecane/TBP was treated by the LPS in 1998. Approximately 205,000 gallons of water were collected from the interceptor trench and transferred to lagoon 2 during the year.

Results of surface and groundwater monitoring in the vicinity of the trench are discussed in Chapter 2 under SDA and NDA Sampling Locations, p.2-6, and in Chapter 3 under Results of Monitoring at the NDA, p.3-13.

Waste Minimization Program. The WVDP formalized a waste minimization program in 1991 to reduce the generation of low-level waste, mixed waste, and hazardous waste. This is an organized, comprehensive, and continual effort to prevent or minimize pollution, and the overall goal of this program is to reduce health and safety risks, protect the environment, and comply with all federal and state regulations. (For more details see the Environmental Compliance Summary: Calendar Year 1998, Waste Minimization and Pollution Prevention [p.ECS-5].)

Pollution Prevention Awareness Program. The WVDP's pollution prevention (P2) awareness program is a significant part of the Project's waste minimization program. The goal of the program is to make all employees aware of the importance of pollution prevention both at work and at home.

A crucial component of the P2 awareness program at the WVDP is the Pollution Prevention Coordinators group. This group of volunteers communicates, shares, and publicizes prevention, reduction, reuse, and recycling information to all departments at the WVDP.

The P2 coordinators identify and facilitate the implementation of effective source reduction, reuse, recycling, and procurement of recycled products. Six self-directed teams evaluate specific concerns and issues and make recommendations for resolution.

Accomplishments of the P2 Awareness Program. As part of the goal of achieving a larger community awareness of pollution prevention, the Pollution Prevention Coordinators organized annual Earth Day activities for WVDP employees and a community outreach that involved a local business, the local school, the WVDP, and the surrounding community. The P2 coordinators also promoted the first WVDP event for National Pollution Prevention Week as well as the first Energy Awareness Month, sponsored by the Department of Energy. In addition, the P2 coordinators created a P2 web page on the site's Intranet that highlights activities, resources, and successes of the Waste Minimization/Pollution Prevention Program.

Waste Management. Significant achievements in 1998 included overall strategy and long-range waste management program planning; waste storage, processing, and off-site disposal; compliance with regulatory requirements; waste volume reduction; and waste minimization and pollution prevention.

- The WVDP Site Technology Coordination group continued to help identify and implement new waste management technologies for WVDP wastes. This group is charged with identifying technology required to meet existing and future waste management goals, evaluating emerging technologies, and promoting technology transfer between DOE facilities, federal agencies, and private industry.
- Improved wastewater technology was incorporated, resulting in a reduction of approximately 1,000 ft³ per year in the volume of ion-exchange resin used for treating north plateau groundwater and for operation of the LLWTF.
- Low-level radioactive waste shipments off-site to licensed treatment, storage, and disposal facilities (TSDFs) totaled 10,422 ft³ in 1998, compared to 4,835 ft³ in 1997.
- Approximately 200,000 lbs of nonradioactive testing glass was sent to a recycling facility in lieu of disposal.
- Excess stocks of mercury thermometers were shipped to area universities for reuse, avoiding disposal as a hazardous waste.
- Decommissioned equipment was radiologically surveyed and released for reuse on-site, resulting in a reduction of approximately 167 ft³ of low-level waste.

Three additional waste management milestones were completed during 1998: Matching Technologies Being Pursued to Site Needs, Classification of Backlog Wastes in Inventory, and Completion of a Soil Management Program.

The Waste Management department also was re-engineered to improve methods of addressing waste management at the WVDP. Reengineering included establishing a baseline database and providing characterization and disposition information during work planning. Other procedural

improvements included container management, staging, and transportation.

National Environmental Policy Act Activities. Under the National Environmental Policy Act (NEPA), the Department of Energy is required to consider the overall environmental effects of its proposed actions or federal projects. The President's Council on Environmental Quality established a screening system of analyses and documentation that requires each proposed action to be categorized according to the extent of its potential environmental effect. The levels of documentation include categorical exclusions (CXs), environmental assessments (EAs), and environmental impact statements (EISs).

Categorical exclusions evaluate and document actions that will not have a significant effect on the environment. Environmental assessments evaluate the extent to which the proposed action will affect the environment. If a proposed action has the potential for significant effects, an environmental impact statement is prepared that describes proposed alternatives to an action and explains the effects.

NEPA activities at the WVDP involve facility maintenance and minor projects that support high-level waste vitrification. These projects are documented and submitted for approval as categorical exclusions, although environmental assessments are occasionally necessary.

In December 1988 the DOE published a Notice of Intent to prepare an environmental impact statement for the completion of the WVDP and closure of the facilities at the WNYNSC. The environmental impact statement describes the potential environmental effects associated with Project completion and various site closure alternatives.

The draft environmental impact statement was completed in 1996 and released for a six-month public review and comment period. Comments

currently are being evaluated. Having met throughout 1997 and 1998 to review alternatives presented in the environmental impact statement, the Citizen Task Force issued the West Valley Citizen Task Force Final Report (July 29, 1998). This report provided recommendations and advice on the development of a preferred alternative. The Citizen Task Force continues to meet and discuss the issues related to this environmental impact statement.

The Nuclear Regulatory Commission (NRC), as a cooperating agency in this environmental impact statement and as part of its responsibilities under the WVDP Act, issued SECY-98-251, Decommissioning Criteria for West Valley (October 30, 1998). This document proposed decommissioning criteria for the WVDP and the West Valley site and identified potential alternatives that may be necessary to ensure acceptable long-term control and care of the site. The NRC staff presented this to the NRC Commissioners for their approval. The DOE, NYSERDA, NYSDEC, and the Citizen Task Force were invited to the briefing. (See the Environmental Compliance Summary: Calendar Year 1998 [p.ECS-14] for a more detailed discussion of specific NEPA activities in 1998.)

A supplement to the draft environmental impact statement is scheduled for release in 1999, with a final version of the EIS expected in 2000.

Self-assessments continued to be conducted in 1998 to review the management and effectiveness of the WVDP environmental protection and monitoring programs. Results of these self-assessments are evaluated and corrective actions are tracked through completion. Overall results of these self-assessments found that the WVDP continued to implement and in some cases improve the quality of the environmental protection and monitoring program. (See the Environmental Compliance Summary: Calendar Year 1998 [p.ECS-19] and Chapter 5, Quality Assurance [p.5-6].)

In addition to the public comment process required by the National Environmental Policy Act, NYSERDA, with participation from the DOE, formed a Citizen Task Force in January 1997. The mission of the Task Force is to assist in the development of a preferred alternative for the completion of the West Valley Demonstration Project and the cleanup, closure, or long-term management of the facilities at the Western New York Nuclear Service Center. The Task Force process has helped illuminate the various interests and concerns of the community, increased the two-way flow of information between the site managers and the community, and provided an effective way for the Task Force members to establish a mutually agreed upon set of recommendations for the site managers to consider in their decision-making process.

Occupational Safety and Environmental Training. The occupational safety of personnel who are involved in industrial operations under DOE cognizance is protected by standards mandated by DOE Order 5480.4, Environmental Protection, Safety, and Health Protection Standards, which directs compliance with specific Occupational Safety and Health Act (OSHA) requirements. This act governs diverse occupational hazards ranging from electrical safety and protection from fire to the handling of hazardous materials. The purpose of OSHA is to maintain a safe and healthy working environment for employees.

Hazardous Waste Operations and Emergency Response regulations require that employees at treatment, storage, and disposal facilities, who

may be exposed to health and safety hazards during hazardous waste operations, receive training appropriate to their job function and responsibilities. The WVDP Environmental, Health, and Safety training matrix identifies the specific training requirements for affected employees.

The WVDP provides the standard twenty-four-hour hazardous waste operations and emergency response training. (Emergency response training includes spill response measures and controlling contamination of groundwater.) Training programs also contain information on waste minimization, pollution prevention, and the WVDP environmental management program. Besides this standard training, employees working in radiological areas receive additional training on subjects such as understanding radiation and radiation warning signs, dosimetry, and respiratory protection. In addition, qualification standards for specific job functions at the site are required and maintained. These programs have evolved into a comprehensive curriculum of knowledge and skills necessary to maintain the health and safety of employees and ensure the continued compliance of the WVDP.

The WVDP maintains a hazardous materials response team that is trained to respond to spills of hazardous materials. This team maintains its proficiency through classroom instruction and scheduled training drills.

Medical emergencies on-site are handled by the WVDP Emergency Medical Response Team. This team consists of on-site professional medical staff, volunteer New York State-certified emergency medical technicians, and main plant operators who are certified as New York State First Responders.

Any person working at the WVDP who has a picture badge receives general employee training covering health and safety, emergency response, and environmental compliance issues. All visitors to the WVDP receive a site-specific briefing

on safety and emergency procedures before being admitted to the site.

ISMS Implementation. An integrated environmental, safety, and health (ES&H) management system (ISMS) was implemented at the WVDP during 1998. The original implementation plan comprised eight key areas to be improved and included writing a safety management system description, developing two new site-specific procedures, and integrating more than thirty key procedures.

Enhanced work planning (EWP) closely matches the core elements of ISMS and was one of the more important areas identified for improvement to successfully implement ISMS at the Project. Organizing the site-wide work review group (WRG) was the most significant EWP initiative. The WRG provides review and input for proposed work documents and, along with other improvements such as up-front worker involvement, satisfied EWP and ISMS requirements. As a result, the EWP and ISMS programs received verification from the DOE Ohio Field Office (i.e., DOE accepted these programs).

Environmental management at the WVDP is integrated with other safety-management processes at the site. Existing environmental management procedures provide the basic policy and direction for accomplishing work through proactive management, environmental stewardship, and integration of appropriate technologies across all Project functions. Potential threats to the environment are evaluated through environmental assessments (EAs) or environmental impact statements (EISs), which are required by the National Environmental Policy Act (NEPA).

The two predominant environmental management systems are the Code of Environmental Management Principles for Federal Agencies (CEMP) and the ISO/DIS 14001, Environmental Management Systems - Specification for Guidance and Use. CEMP was developed by the EPA in re-

sponse to Executive Order 12856, Federal Compliance with Right-to-Know Laws and Pollution Prevention Requirements. CEMP uses five broad principles and underlying performance objectives as the basis for federal agencies to move toward responsible environmental management. These principles help ensure environmental performance that is proactive, flexible, cost-effective, integrated, and sustainable. ISO/DIS 14001, developed by the International Organization for Standardization (ISO), provides a comparable environmental management system that is being implemented throughout the world. The elements of an environmental management system correspond to the guiding principles and core functions of an integrated safety management system.

EMS Implementation. The environmental management system at the WVDP encompasses the requirements of both the CEMP and ISO 14001. This system allows the effects of site activities on the environment to be considered; follows practices that eliminate or minimize negative effects; includes monitoring and compliance with all applicable environmental laws, regulations, and requirements; and requires the management of programs, projects, and activities in a manner that protects the environment and public health.

Performance Measures

Performance measures can be used to evaluate effectiveness, efficiency, quality, timeliness, productivity, safety, or other areas that reflect achievements related to organization or process goals and can be used as a tool to identify the need to institute changes.

Several performance measures applicable to operations conducted at the WVDP are discussed below. These measures reflect process performance related to wastewater treatment in the low-level waste treatment facility, the identification of spills and releases, the reduction in the generation of wastes, the potential radiological dose received by the maximally exposed off-site individual, and the transfer of high-level waste to the vitrification system.

Radiation Doses to the Maximally Exposed Off-Site Individual. One of the most important pieces of information derived from environmental monitoring program data is the potential radiological dose to an off-site individual from on-site activities. As an overall assessment of Project activities and the effectiveness of the as-low-as-reasonably achievable (ALARA) concept, the effective radiological dose to the maxi-

mally exposed off-site individual is an indicator of well-managed radiological operations. The effective dose equivalent for air effluent emissions, liquid effluent discharges, and other liquid releases (such as swamp drainage) from 1993 through 1998 are graphed in Figure 1-1 (*this page*). Note that the sum of these values is well below the DOE standard of 100 mrem. These consistently low results indicate that radiological activities




Figure 1-1. Annual Effective Dose Equivalent to the Maximally Exposed Off-site Individual

at the site are well-controlled. (See also Table 4-2 [p.4-7] in Chapter 4, Radiological Dose Assessment.)

SPDES Permit Limit Exceedances. Effective operation of the site wastewater treatment facilities is indicated by compliance with the applicable discharge permit limitations. Approximately sixty parameters are monitored regularly as part of the SPDES permit requirements. The analytical results are reported to the state via Discharge Monitoring Reports required under the SPDES program.

Although the goal of the low-level waste treatment facility (LLWTF) and wastewater treatment facility (WWTF) operations is to maintain effluent water quality consistently within the permit requirements, occasionally SPDES permit limit exceedances do occur. A Water Task Team composed of WVDP personnel with expertise in wastewater engineering, treatment plant operations and process monitoring, and NPDES/SPDES permitting and compliance was formed in 1995 to address the causes of these exceptions.

All SPDES permit limit exceedances are evaluated to determine their cause and to identify corrective measures. In recent years, virtually all of the recorded exceptions were for parameters such as nitrite, pH, and five-day biochemical oxygen demand (BOD₅), which regulate or are greatly influenced by natural (microbiological) treatment processes occurring at the site's industrial and sanitary WWTF and the LLWTF. However, there were no exceedances during 1998.

Although exceedances are not always related to operating deficiencies, corrective actions may include improved operation or treatment techniques. Some examples of the problems solved over the last four years are as follows:

- Elevated concentrations of nitrogen-based nutrients (nitrite, in particular) at the LLWTF

Nitrite is normally an intermediate compound formed during microbiological conversion of ammonia to nitrate. The conversion process was inhibited by excess nitrate, pH below 6.0 standard units, and cold weather. This was remedied through better control of pH in the open-air lagoons, enhanced process monitoring to detect substantial changes in nutrient concentrations in the lagoons, and elimination of nitric acid from the filter backflush (cleaning) procedure. Eliminating nitric acid became feasible when the anthracite filter media was replaced with sand filter media, which can be effectively backflushed with softened water. Since the replacement filter began operating, nitrate (as nitrogen) concentrations have been reduced by approximately 90% and no permit exceptions for nitrite (as nitrogen) have occurred.

- Excess algae in the LLWTF lagoons

Seasonal algal growth caused elevated oxygen demand and fluctuating pH conditions in the LLWTF effluent holding lagoons. This was remedied by adding hydrogen peroxide to the water treatment process, consistent sparging (aeration) of the lagoons to increase dissolved oxygen content, using filter socks to capture particulates entrained in the effluent water column, and modifying the SPDES permit with a revised method for determining compliance with the limit for BOD₅ that takes into consideration the cumulative contribution of all Project-regulated effluents rather than individual discharges.

- Elevated nitrite and BOD₅ at the WWTF

Sudden weather-induced temperature changes in the WWTF influent, which was stored in an open-air flow equalization basin, affected the performance of this microbiological (activated sludge)-based treatment process. An underground influent surge tank was installed

in 1997 to make efficient use of the insulating effect of the surrounding soil. Since that time, discharge monitoring results for these parameters have remained within permit limits.

- Changes in receiving stream conditions between sample collection events causing elevated total dissolved solids in Frank's Creek

Augmentation water from the site reservoirs is used to control the total dissolved solids concentrations in Frank's Creek during lagoon discharges. The delay associated with off-site shipment and analysis of permit-required process control samples created a significant time interval for stream conditions to change without an appropriate adjustment in augmentation flow to ensure compliance. On-site analysis for total dissolved solids was implemented, which shortened the time interval from sample collection and analysis to flow adjustment and reduced the associated risk for undetected changes in receiving stream conditions during this time period.

- Surface Water Infiltration Projects

Two projects were implemented to divert surface water away from the main plume area on the north plateau. These projects involved capturing surface water runoff from the north parking lot area and placing a low permeability soil layer east of the north parking area.

The Water Task Team's efforts have produced significant results, as shown in Figure 1-2 (*this page*), which graphs the number of SPDES permit exceedances from calendar years 1993 through 1998. The annual number of exceptions to the numerical discharge limits in the site's SPDES permit have been substantially reduced, and in 1998, for the first time since the DOE began operating the Project (in 1982), no exceptions occurred.

Waste Minimization and Pollution Prevention. The WVDP has initiated a program to reduce the quantities of waste generated from site activities. Reductions in the generation of low-level radioactive waste, radioactive mixed waste, hazardous waste, industrial wastes, and sanitary wastes such as paper, glass, plastic, wood, and scrap metal were targeted. To demonstrate the effectiveness of the waste minimization program, a graph of the percentage of waste reduction achieved above the annual goal for each category is presented in Figure 1-3 (p.1-16) for calendar years 1993 through 1998. Not all waste streams have been tracked over this period. Note that the low-level radioactive waste figures from 1993 through 1995 include the volume of drummed waste produced in the cement solidification system. The hazardous waste quantity for 1994 also includes about 1,900 kilograms (4,200 lbs) of waste produced in preparing for vitrification. Hazardous waste and industrial waste volumes have been tracked separately for vitrification-related and nonvitrification-related waste streams since vitrification began in 1996. To maintain historical comparability, the percentages in Figure 1-3 include only the nonvitrification portions of these two waste streams.




Figure 1-2. Yearly SPDES Permit Exceedances




Figure 1-3. Percentage of Waste Reduction Exceeding Annual Goals

Spills and Releases. Chemical spills greater than the applicable reportable quantity must be reported immediately to NYSDEC and the National Response Center and other agencies as required. There were no reportable chemical spills during 1998.

Petroleum spills greater than 5 gallons or of any amount that travel to waters of the state must be reported immediately to the NYSDEC spill hotline and entered in the monthly log. There were two minor spills of petroleum immediately reportable to NYSDEC in 1998. Each of these two releases included less than 1 gallon of diesel fuel that was spilled on paved areas and was promptly contained and cleaned up by site personnel. Figure 1-4 (*this page*) is a bar graph of immediately reportable spills from 1992 to 1998.

Prevention is the best means of protection against oil, chemical, and hazardous substance spills or releases. WVDP employees are trained in appli-

cable standard operating procedures for equipment that they use, and best management practices have been developed that identify potential spill sources and present measures to reduce the potential for releases to occur. Spill training, notification, and reporting policies have also been developed to emphasize the responsibility of each employee to report spills immediately upon discovery. This first-line reporting helps to ensure that spills will be properly documented and mitigated in accordance with applicable regulations.

Vitrification. A primary objective of the West Valley Demonstration Project is to safely solidify the high-level radioactive waste at the site in borosilicate glass. To do this, the high-level waste sludge is transferred in batches from the tank

where it currently is stored to the vitrification facility. After transfer, the waste is solidified into a durable glass for safe storage and future transport to a federal repository. It is estimated that 11 million to 12 million curies of strontium and cesium radioactivity in the high-level waste even-




Figure 1-4. Number of Immediately Reportable Spills or Releases

tually will be vitrified. (Radioactive cesium and strontium isotopes account for 98% of the long-lived radioactivity.) To quantify the progress made toward completing the vitrification goal, Figure 1-5 (*this page*) shows the number of curies transferred per month to the vitrification facility in 1998.

On June 10, 1998, the WVDP marked completion of the Project's production phase (Phase I) of high-level waste processing. This milestone included safely vitrifying 85% of the high-level waste inventory in 210 canisters of solidified waste glass and immobilizing more than 9.3 million curies of radioactivity. A total of 230 canisters were filled and more than 10.3 million curies were immobilized through vitrification by year end, bringing the cumulative Project total of immobilized liquid high-level waste to more than 20 million curies, including pre-treatment and vitrification.




Figure 1-5. Number of Curies Transferred to the Vitrification Facility per Month